



RESET FILTER-ICON ON YOUR DEVICE

P130/P230/P300/P370

P130



1




3 sec.

2

P230




1




3 sec.

2

P300/P370



1




5 sec.

2


RESET FILTER-ICON ON YOUR DEVICE

P340/P400/P500/P710

P340




1




2

P400/P500




1




2

P710




1




2

RESET FILTER-ICON ON YOUR DEVICE H680

H680



1



2